



## Bigfoot Base Cap - instructions

- Select the appropriate size Cap for the Bigfoot
- Place a 3/8" to 1/2" bead of DAP – water tight roof sealant – around the outer edge of the Cap at the lip
- Place the Bigfoot on the sealant, pressing it firmly into the sealant
- Screw the Bigfoot to the Cap with eight 1" screws evenly spaced around the outer edge of the Bigfoot
- Using 2" long strips of duct tape, cover all the air holes on the Bigfoot
- Once the tube size has been selected, cut the rings off the Bigfoot above the ring being used
- Place a 1/2" bead of sealant around the ring and slide the tube on the Bigfoot into the sealant
- Secure the tube to Bigfoot with four-to-six 1" screws
- Visually inspect all areas where sealant has been used to ensure there are no gaps where water may enter
- Place the system in the water and add just enough concrete, approximately 13 shovels-full, to sink the system
- Position the system in place and backfilling
- Continue filling with concrete to the top